

Determination of Hormones in Water by Solid-Phase Extraction (SPE) and Liquid Chromatography – Tandem Mass Spectrometry (LC-MS/MS)*

UCT Part Number: **EUC18156** (500 mg unendcapped C18, 6 mL)

November 2012

Analytes

Analyte	CASRN
Estriol 16α-Hydroxyestradiol	50-27-1
17β-Estradiol	50-28-2
17α-Ethynylestradiol	57-63-6
Testosterone	58-22-0
Estrone 3-hydroxy-13-methyl-6,7,8,9,11,12,13,14,15,16- decahydrocyclopenta[a]phenanthren-17-one	53-16-7
4-Androstene-3,17-dione	63-05-8
Equilin 3-hydroxyestra-1,3,5,7-tetraen-17-one	474-86-2

Method Summary

Water samples are dechlorinated with sodium thiosulfate and protected from microbial degradation with 2-mercaptopyridine-1-oxide sodium salt during collection. Samples are fortified with surrogates and extracted using C18 cartridges before elution with methanol. The extract is concentrated to dryness with N_2 before adjusting to a 1-mL volume with 50:50 methanol:water. An aliquot is injected into an LC equipped with a C18 column interfaced to a MS/MS. Detection limits of 0.02-0.37 ng/L can be obtained using this application from samples fortified at 0.25-0.875 ng/mL.

Safety

- The toxicity and carcinogenicity of each reagent has not been defined
- Each chemical should be treated as a potential health hazard and exposure minimized by the use of PPE (personal protective equipment) such as gloves, respirators and other personal safety equipment
- Pure standard materials and stock standard solutions of the method compounds should be handled with suitable protection
- Ammonium hydroxide, used during method development as a pH modifier for the HPLC mobile phase, should be fresh* and handled in a fume hood

Sample Collection, Preservation, and Storage

- Use one-liter amber glass bottles with PTFE-lined screw caps
- If smaller sample sizes are used, adjust the amount of preservatives and surrogate/analyte fortification levels according to the sample size
- Fill sample bottles taking care not to flush out the preservatives. Analytes are not volatile so bottles need not be headspace-free
- When sampling from a cold water tap, remove the aerator and allow the system
 to flush until the water temperature has stabilized. Invert the bottles several
 times to mix the sample with the preservation reagents
- Samples should be chilled during shipment and should not exceed 10° C during the first 48 hours after collection
- In the laboratory, store samples at or below 6° C and protect from light until analysis. **Do not freeze unprocessed samples**
- All compounds listed in the method have adequate stability for 28 days when collected, preserved, shipped and stored as described
- Samples should be extracted as soon as possible for best results
- After sample preparation, extracted samples should be stored at 0° C or less and analyzed within 28 days after extraction

Sample Preservatives

Compound	Amount	Purpose
Sodium thiosulfate	80 mg/L	Removes free chlorine
2-mercaptopyridine-1-oxide sodium salt	65 mg/L	Microbial inhibitor

Note: Preservation reagents listed above should be added to each sample bottle prior to shipment to the field or prior to sample collection

^{*}NH₄OH loses its strength after opening due to evaporation. A fresh bottle should be used

Interferences

- Matrix interferences may be caused by contaminants that are co-extracted from the sample and will vary from source to source
- Humic and/or fulvic material in environmental samples may be co-extracted during SPE and can cause enhancement and/or suppression in the electrospray ionization source. Total organic carbon (TOC) is an indicator of the humic content of a sample
- Use only high purity analogs. Depending on the source and purity, labeled analogs used as internal standards may contain a small percentage of the corresponding native analyte which may be significant when attempting to determine LCMRLs and DLs
- Nitrile gloves should be worn at all times. Handling clean glassware may be a potential source of interference
- It may be appropriate to include a Field Blank with the sampling bottles
 depending on the sampling site. The Field Blank is analyzed along with the
 samples to ensure that no human hormones were introduced into the samples
 during the collection and handling process

Internal Standards

Internal Standard	CASRN	Neat Material Cat #	Solution Standard Cat #	
16α-Hydroxyestradiol-d2 (Estriol-d2)	53866-32-3	C/D/N Isotopes Cat. No. D-5279	N/A	
¹³ C6-Estradiol	None	None	Cambridge Isotope Labs 100 μg/mL in Methanol Cat. No. CLM-7936-1.2	
¹³ C2-Ethynylestradiol	None	None	Cambridge Isotope Labs 100 µg/mL in Acetonitrile Cat. No. CLM-3375-1.2	
Testosterone-d3	77546-39-5	None	Sigma Drug Std., 100 μg/mL in dimethoxyethane Cat. No. T5536	

Internal Standard Stock Standards

ISSSS 500 \mug/mL - Weigh 5 mg of α -hydroxyestradiol- d_2 (estriol- d_2) into a tared 10-mL volumetric flask and dilute to volume with methanol. The remaining internal standards can be purchased as 100 μ g/mL solutions

Internal Standard Primary Dilution Standard (IS-PDS)

IS PDS 1.0 – 4.0 \mug/mL: The table below can be used as a guide for preparing the IS PDS. The IS PDS is prepared in acetonitrile and is stable for about six months if stored at a temperature < 6° C. Use 5 μ L of the 1.0 – 4.0 μ g/mL IS PDS to fortify the final 1-mL extracts. This will yield a final concentration of 5.0 – 20 μ g/mL of each IS.

Internal Standard Concentrations

Internal Standard	Conc IS Vol ndard Stock IS µg/mL		Final Volume of IS PDS,	Final Conc. of IS PDS (µg/mL)	
16α- Hydroxyestradiol-d2 (Estriol-d2)	500	40	10	2.0	
¹³ C6-Estradiol	100	100 400		4.0	
13 _{C2-} Ethynylestradiol	100	400	10	4.0	
Testosterone-d3	100	100	10	1.0	

Internal Standard Fortification Standard

 $5~\mu L$ of the IS PDS is difficult to accurately and reproducibly transfer into HPLC vials. Therefore, a 1-in-10 dilution of the IS PDS is prepared by transferring 1-mL of the 1.0 – 4.0 $\mu g/mL$ IS PDS into a 10-mL volumetric flasks and diluting to volume with methanol. This results in a 0.1-0.4 $\mu g/mL$ IS solution

50 μL of the prepared ISPDS is added to the samples prior to analysis

Surrogate Analytes

Two isotopically labeled surrogates are listed below. Select the surrogate that performs best under the LC-MS/MS conditions employed for the analysis

For this application, Bisphenol A-d₁₆ was chosen as surrogate analyte

Surrogate Analytes

Surrogate Analyte	Neat Materials Catalog No.	
Ethynylestradiol- <i>d</i> ₄	350820-06-3	C/D/N Isotopes, Cat. No. D-4319
Bisphenol A-d ₁₆	96210-87-6	Sigma, Cat. No. 451835

Surrogate Stock Standards

 $1000 \ \mu g/mL$ - Prepare individual solutions of the surrogate standards by weighing 10 mg of the solid material into tared 10-mL volumetric flasks and diluting to volume with methanol

Surrogate Analyte Primary Dilution Standard

SUR PDS $2.5-7.0~\mu g/mL$ - Use the table below as a guide for preparation of the **SUR PDS** in methanol. Use 10 μ L of **SUR PDS** to fortify 1-L samples yielding a final concentration of 70 ng/mL ethynylestradiol- d_4 or 25 ng/mL bisphenol A- d_{16} in the 1-mL extracts

Surrogate Analyte Solutions

Surrogate Analyte	Conc of SUR Stock (µg/mL)	Volume of SUR Stock (µg/mL)	Final Volume of SUR PDS (mL)	Final Conc. Of SUR PDS (μ g/mL)
Ethynylestradiol-d ₄ 1000		70	10	7.0
Bisphenol A-d ₁₆ 1000		25	10	2.5

Surrogate Fortification Standard (SUR PDS)

10 μ L of the **SUR PDS** is difficult to accurately and reproducibly transfer into samples. Therefore, a 1-in-10 dilution of the **SUR PDS** is prepared by transferring 1-mL of the 2.5 μ g/mL IS PDS into a 10-mL volumetric flask and diluting to volume with methanol, resulting in a 0.25 μ g/mL IS solution. Use 100 μ L of this fortification standard to fortify 1-L samples yielding a final concentration of 25 ng/mL bisphenol A-d16 in the 1-mL extracts

Analyte Stock Standard Solution

Each concentration equals 1000 µg/mL - Obtain the analytes listed in Table 1 above as standard solutions or as neat materials. Prepare stock standards individually by weighing 10 mg of the solid standards into tared 10-mL volumetric flasks and diluting to

Analyte Primary Dilution Standard

Prepare concentrations of the stock standard solutions between 1.0 - 3.5 $\mu g/mL$ - Dilute the Analyte Stock Standard solutions into 50% methanol in reagent water. The concentrations vary based on the instrumental sensitivity. The Analyte PDS is used to prepare calibration standards, and to fortify LFBs, LFSMs, and LFSMDs with the method analyte

Analyte Concentrations

Analyte Stock			Final Volume (ml, 50% MeOH)	Analyte PDS Concentration µg/L
Estriol, 16α- Hydroxyestradiol	100 0	20		2.0
Estrone	100 0	20		2.0
17β-Estradiol	100 0	25		2.5
17α-Ethynylestradiol	100 0	35	10	3.5
Equilin	100 0 20		2.0	
Androstenedione	e 100 0 10		1.0	
Testosterone	100 0	10		1.0

Analyte Fortification Standard

10 μL of the Analyte PDS is difficult to accurately and reproducibly pipette into samples. Therefore, a 1-in-10 dilution of the Analyte PDS is prepared by transferring 1-mL of the 1.0 – 3.5 $\mu g/mL$ Analyte PDS into a 10-mL volumetric flask and diluting to volume with 50% methanol, resulting in a 0.1 – 0.35 $\mu g/mL$ solution. Use 100 μL of this fortification standard to fortify 1-L samples yielding a final concentration of 10 – 35 $\mu g/mL$ in the 1-mL extracts.

An additional 1-in-10 dilution of the $0.1-0.35~\mu g/mL$ fortification solution is prepared in a 10-mL volumetric flask using 50% methanol. This yields a $0.01-0.035~\mu g/mL$ solution that is used to fortify 1-L samples yielding a final concentration of 1-3.5~ng/mL in the 1-mL extracts.

Procedure

1. Sample Preparation

- a) Add a 100-µL aliquot of SUR Fortification Standard to each 1-L sample for a final concentration of 25 ng/L bisphenol A-d₁₆
- b) Fortify LFBs, LFSMs, or LFSMDs with an appropriate volume of Analyte Fortification Standard
- c) Cap and invert each sample several times to mix

2. SPE Procedure

- Assemble a vacuum manifold. Automated extraction equipment may also be used
- b) Place **EUC18156** cartridge(s) on the manifold
- c) Add a 10-mL aliquot of methanol to the cartridge and draw through the cartridge until dry
- d) Add another 5-mL aliquot of methanol and draw through the cartridge until dry

Note: Do Not Let the Cartridge Go Dry after Starting the Following Steps

- e) Add approximately 10-mL of methanol to each cartridge
- f) Draw about 1 mL of solvent through the cartridge and turn off the vacuum temporarily
- g) Let the cartridge soak for about one minute then draw most of the remaining solvent through the cartridge leaving a thin layer of methanol on the surface of the cartridge
- h) Add 10-mL of reagent water to each cartridge and draw through leaving a thin layer of liquid on the surface of the cartridge
- i) Add another 10-mL aliquot of reagent water
- j) Draw the water through the cartridge keeping the water level above the cartridge surface
- k) Turn off the vacuum

3. Sample Extraction

- a) Add the sample to the extraction reservoir containing the conditioned cartridge and turn on the vacuum (approximately 10 to 15 in. Hg). Flow of sample through the cartridge should be a fast drip. Adjust vacuum if necessary
- b) Do not let the cartridge go dry before the entire sample volume is extracted
- c) After the entire sample has been drawn through the cartridge, add a 10-mL aliquot of 15% methanol to the sample container and wash the cartridge with the rinsate from the container
- d) Using full vacuum, draw air through the cartridge by maintaining full vacuum for 10–15 minutes
- e) After drying, turn off and release the vacuum

4. Sorbent Elution

- a) Insert collection tubes into the manifold to collect the cartridge extracts. The collection tube should fit around the drip tip of the base to ensure collection of all the eluent
- b) Add 5-mL of methanol to the cartridge and draw the methanol into the cartridge to soak the sorbent
- c) Allow the cartridge to soak for about one minute
- d) Using vacuum, draw the remaining methanol slowly through the cartridge into the collection tube
- e) Elute with an additional 2 x 5-mL aliquots of methanol

Note: The methanol can be eluted directly into a 15-mL tube (or larger). Otherwise 5-mL MeOH can be eluted into a 5 mL culture tube and evaporated to near dryness prior to adding the second 5-mL eluate. This process is repeated until all 15-mL MeOH has been added to the 5 mL culture tube.

5. Extract Concentration

- a) Concentrate the extract to dryness under a gentle stream of N₂ in a warm water bath (~45° C)
- b) Rinse the collection tube with 950 μ L of 50% methanol, vortex for 2 min and transfer the rinse into a HPLC vial
- c) Add 50µ I IS Fortification Standard (ISFS) and vortex for an additional 1 min

6. Sample Filtration

- a) It is highly recommended that extracts be filtered with at least a 0.45 micron syringe filter prior to analysis to remove the particulates in a sample.
- b) If filtering is incorporated as part of the sample preparation, the first lot of syringe filters should be included in the procedure to document the potential interferences that are introduced or analytes are retained on the filter.
- c) Subsequent lots of syringe filters can be verified by examining CAL standards.

Sample Analysis

HPLC Conditions

HPLC instrument: Thermo Scientific Dionex UltiMate 3000 System**

Column: Thermo Scientific Accucore C18, 100 x 2.1 mm, 2.6 µm with 10 mm guard column

Column Temperature: 35° C

Column Flow Rate: 0.200 mL/min

Injection Volume: 20 ul

injection volume. 20 µL								
Gradient								
Time (min)	Moblie phase A H₂O + 0.02% NH4OH	Moblie phase B MeOH +0.02% NH4OH						
0	70	30						
1	35	65						
9	35	65						
9.1	15	85						
11	15	85						
11.1	70	30						
15	70	30						

ESI-MS/MS Method Conditions

MS Par	MS Parameters					
MS instrument	Thermo Scientific TSQ Vantage**					
Polarity	HESI ⁺ & HESI ⁻					
Spray Voltage V	+4500 / -3500 V					
Vaporizer Temperature	350°C					
Ion Transfer Capillary Temperature	300 °C					
Sheath Gas Pressure	45 arbitrary units					
Auxiliary Gas Pressure	40 arbitrary units					
Q1 and Q3 Peak Width (FWHM)	0.4 and 0.7 Da					
Collision Gas and Pressure	Ar at 1.5 mTorr					
Scan Type	SRM					
Cycle Time	0.75 Sec					

^{**}Alternative LC-MS/MS systems may be used

LC-ESI-MS/MS Analyte Retention Times, Precursor and Product Ions, S-lens, and Collision Energy

Analyte	Ret. Time (min.)	ESI Mode	Precursor Ion		S-lens V	Collision Energy eV	Internal Standard
Estriol	4.99	ESI-	286.75	144.96	100	39	Estriol-d2
Bisphenol A-d ₁₆	6.20	ESI-	240.91	223.02	60	18	¹³ C ₆ -Estradiol
Equilin	7.03	ESI-	266.80	142.97	67	37	¹³ C6-Estradiol
17β-Estradiol	7.14	ESI-	270.93	144.98	67	40	¹³ C6-Estradiol
Androstenedione	7.18	ESI+	286.87	96.88	76	20	Testosterone-d3
17α- Ethynylestradiol	7.19	ESI-	294.79	244.97	80	39	13 _{C2} - Ethynylestradiol
Estrone	7.24	ESI-	268.78	144.97	109	39	13 _{C2} - Ethynylestradiol
Testosterone	7.76	ESI+	288.96	96.88	76	20	Testosterone-d3

LC-ESI-MS/MS Internal Standard Retention Times, Precursor and Product Ions, Slens, and Collision Energy

Internal Standard	Ret. Time (m	Precursor Ion	Product Ion	S- Lens V	Collision Energy eV
Estriol-d2	5.00	288.75	146.96	100	39
¹³ C6-Estradiol	7.13	276.93	146.98	67	40
13 _{C2} -Ethynylestradiol	7.16	296.80	144.97	80	39
Testosterone-d3	7.73	291.96	96.88	70	20

Analyte Recovery

n = 5	Estriol	Equilin	Estradiol	Androstenedione	Testosterone	Ethynylestradiol	Estrone
Fortified Conc (ng/mL)	20	20	25	10	20	10	35
Mean	97.61	82.81	96.98	92.88	90.76	96.49	93.95
SD	6.45	5.90	5.17	2.55	3.47	1.31	2.02
RSD	6.60	7.13	5.33	2.75	3.82	1.36	2.15

n = 5	Estriol	Equilin	Estradiol	Androstenedione	Testosterone	Ethynylestradiol	Estrone
Fortified Conc (ng/mL)	2	2	2.5	1	1	3.5	2
Mean	83.05	96.34	93.68	98.31	104.63	109.45	106.10
SD	4.02	8.92	7.02	3.90	4.95	6.96	6.19
RSD	4.84	9.26	7.49	3.96	4.73	6.36	5.84

^{*}Based on EPA Method 539, Version 1.0, November 2010, Glynda A. Smith (U.S. EPA, Office of Ground Water and Drinking Water) Alan D. Zaffiro, (Shaw Environmental, Inc.) M. L. Zimmerman (Shaw Environmental, Inc.) D. J. Munch (U.S. EPA, Office Of Ground Water And Drinking Water), Technical Support Center, Standards And Risk Management Division, Office Of Ground Water And Drinking Water, U.S. Environmental Protection Agency, Cincinnati, Ohio 45268

UCT, LLC • 2731 Bartram Road • Bristol, PA 19007 • 800.385.3153 • 215.781.9255 • www.unitedchem.com • Email: methods@unitedchem.com ©UCT, LLC 2012 • All rights reserved

DCN-216111- 249

UCT, LLC • 2731 Bartram Road • Bristol, PA 19007 • 800.385.3153 • 215.781.9255 • www.unitedchem.com • Email: methods@unitedchem.com ©UCT, LLC 2012 • All rights reserved